

INSTRUCTIONS FOR INSTALLING OLIVE BARREL HYDRO HOUSING

Locate barrel on firm ground, where pipe ends.

When barrel is in the desired place, place a few large rocks in the bottom to secure it. The bottom will fill with silt up to the discharge pipe after use.

Direct the discharge pipe towards the creek and place the hydro on the platform.

Turn the platform to align the hydro to the manifold and drill the holes for the inlets to align with the nozzle tubes, using a hole saw. You can also cut the plastic with a knife. It's easier if you warm the spot you intend to cut with a torch, before using a knife.

Heat the poly pipe first, before attaching it to the drain.

After connecting the wires to the right terminals, turn the hydro on to make sure the barrel does not flood. A longer piece of the discharge tube will siphon more water out the barrel, if it does flood. If flooding persists, install a second or larger drain and pipe.