

## Air Heater Diversion Load Installation Instructions

### **WARNING:**

**During operation, the box may become extremely hot.**

The diversion load should be mounted vertically on a non-flammable surface, where nothing will be placed on top or leaned against it. If mounted on a wooden wall, use a piece of cement board and space the box away from the wall with spacers or nuts. It should be at least 12" from any uncovered flammable material.

The resistors are non-polar. It doesn't matter which connection in the resistor box you use for positive and negative. Connect one terminal to common negative connection in regulator box. Connect other connection to terminal marked "PV/Load" in Xantrex or Morningstar.